

ALARM - Instructions

Alarm is for your own safety. It is the responsibility of the guest to use alarm or not.



Inside keypad next to the front door

Symbols



= OFF / De-activated/ Unlock



= ON / Activated/ Lock



Outside keypad for exterior alarm: on the parking lot near the kitchen window

Activating Interior alarm (LOCK ON):

Not if you somebody is inside the house (day or night) yourself!!!

Activating INTERIOR ALARM ON: Press code 3490 and the button LOCK/ON.

You hear a beep for 30 SEC and red light comes on.
Go directly outside and close the door (within 30 sec).

WHEN COMING HOME:

Open the door and within 30 sec:

De-activating Interior Alarm: press code 3490 and the button UNLOCK/OFF):

If you do hear the alarm sirene: just follow the steps for ALARM OFF

Activating Exterior alarm (LOCK ON):

1. WHEN INSIDE THE HOUSE (Before going to sleep).

Use the inside keypad → same procedure for INTERIOR but then use EXTERIOR

2. WHEN GOING OUT:

Use the keypad on the wall near the kitchen window

Close the front door, walk out.

Activating EXTERIOR Alarm: press code 3490, then press LOCK/ON

Red light on the key path will go on. You will hear a beep for 1 minute.

3. WHEN COMING HOME

Open the gate

De-activating/ turn off EXTERIOR ALARM: press_code 3490 and then press UNLOCK/OFF

If you do hear the alarm sirene: just follow the steps for ALARM OFF

OFF CAMERA ON

In the garden there is a camera in 3 places: parking, back side of the house and one on the wall opposite to the outside shower.

For privacy reasons, the camera default is OFF.